




**Ancien couvercle Coupe-Légumes
For old vegetable slicer lid**



▲ Ce couvercle n'est plus disponible.
Commander l'index 29, vous recevrez le nouveau couvercle coupe-légumes complet.
This lid is no more available.
Order item 29, you will receive the complete new vegetable lid attachment.

**Ancien variateur
Old variator**

L'ancien potentiomètre P est remplacé par l'ensemble 20.
The old potentiometer P is replaced by the assembly 20.



L'ancien variateur n'est plus disponible, pour le remplacer commander le **kit de mise à niveau V1**.
Vous recevrez le nouveau variateur V2, le socle B2, la carte boutons C2, le support variateur 22, les vis et la notice.
Si vous avez déjà remplacé votre variateur par un nouveau, passez à la colonne "Nouveau variateur".

ATTENTION : Si votre appareil est équipé du potentiomètre P, alors commander en plus le nouveau potentiomètre 20.

The old variator is no longer available, to replace it, order the **upgrade kit V1**. You will receive the new variator V2, the base B2, the controls board C2, the variator support 22, the screws and the technical instructions.
If you have already changed your variator by a new one, use column "New variator".

CAUTION : If your machine is equipped with the potentiometer P, then order in addition the new potentiometer item 20.